

ACCESSING SCALE SETUP FROM MS DOS MODE

- Install “Colormix MS DOS Service Disk” in the floppy drive of your computer and restart the PC.
- The first menu displayed is the “COLORMIX SERVICE” menu. Select “SCALE TEST” and press <ENTER>. The Colormix logo will be displayed.
- Press the F3 key for the scale menu settings. Select “SCALE SETUP” and press <ENTER>.
- Use the up and down arrows on the colormix keyboard to select the desired function that you wish to change. Press <ENTER> at the desired function for a sub menu of available settings. A check mark next to a highlighted setting indicates the active menu setting. Scroll up and down to your desired selection and press <ENTER> again.
- When you are finished making the desired changes, scroll down to the “SAVE SETTINGS” function and press <ENTER>. The scale will prompt you to “save settings?” Press <ENTER> for yes. Failure to do this will not activate the settings that you have chosen, and you will have to reset your variables. The weigh window will enter a brief segment check.
- Scroll down again to “LEAVE MENU” to return to the Setup menu. Select “QUIT PROGRAM” to leave the setup menu.
- You may now tare or calibrate the scale at the Colormix logo displayed by pressing either F1 for TARE, or F2 for CAL.
- Select F4 to return to the original COLORMIX TEST menu. Scroll down to “EXIT TO OP. SYSTEM” and press <ENTER>. This will return you to the DOS prompt.

Please note: There are certain functions on the disk that are not accessible without special Sartorius test hardware. Any failures in these tests are normal without the required equipment.

Should you need further assistance, please call 1-800-635-2906 ext. 8337.