

**COLORMIX MENU ACCESS PROCEDURE**

From Windows95:

- 1) Start Windows95. Click on "Find".
- 2) Go to "Files or Folders".
- 3) In the "Named" edit field, type the following: ScaleSetup.exe (Important Note: Type this file name **exactly** as it appears, noting that there is no space between "scale" and "setup".)
- 4) In the "Look In" edit field, select the "C:\\" entry. (Be sure that "check all subdirectories" is enabled)
- 5) Click on "Find Now".
- 6) If the search proves unsuccessful, try another search, but this time try selecting another drive. If the file is still not found, please contact your Software Support Entity.
- 7) Click on the small icon next to the "ScaleSetup" filename. This will start the scale setup program.
- 8) Before you can change any settings in the menu, you will have to establish the scale connection first. On the top of the menu screen, you will see an edit field called "Interface". Click on the down arrow to the right side of the field to give you a selection of available COM ports. Select COM 1 and click on it.
- 9) The system will attempt to establish the connection between the scale and the computer. Once successful, the selections to adjust the menu will be highlighted, and you may select the desired parameters by pointing and clicking on the appropriate settings.
- 10) When you are done making the desired changes, you must lock the changed you made into the computer. If you are finished, simply click on "Save and Exit" to return to the "Find File" window. The settings will be activated.
- 11) You can also Tare and Calibrate the scale from the Scale Setup window. Point and click on your selection. To calibrate, click on "Calibrate". In the weigh window, or lower display, you will see "5000.0" with "CAL" and a small "+" sign on the left side of the display. Place a 5000g weight on the pan. After a few seconds, the display will briefly flash, and then display "5000.0g" the "CAL +" will disappear, and the unit is now calibrated. Click on "Save and Exit" to leave the Scale Setup program.

Should you have any questions, please contact Sartorius Corporation at 1-800-635-2906 ext. 8337 for assistance.